

Johnson-Rose Inc

Parts Diagram for French Fry Cutter
 Product #

French Fry Cutter List

Item	Description	Item	Description
H1	Handle	H10	Pusher Connector Casting
H2	Bolt Nut and Screw	H11	Pusher Connector Screw
H3	Front End Casting	H12	Pusher Block Screw
H4	Wing Nut	H13	Link
H5	Slide Rod	H14	Blade Locking Screw
H6	Slide Rod Nut	H15	1/2" (.9 cm) Cutting Frame
H7	Back End Cast	H15C	1/4" (.6 cm) Cutting Frame
H8	Link Connector Screw & Nut	H15F	3/8" (1.3 cm) Cutting frame
H9	Potato Pusher	H16	3/8" Pusher Block
K250BL	Blades Only	H16P	1/4" Pusher Block
K375BL	Blades Only	H16B	1/2" Pusher Block
K500BL	Blades Only	H17	Tray

